LINKSYS®
A Division of Cisco Systems, Inc.

Package Contents

- One PCM1000 Gigabit Notebook Adapter
- Setup Wizard CD-ROM with User Guide in PDF format
- One Quick Install ation Guide
- Network Cable
- Registration Card

Gigabit Notebook Adapter

WIRED

Quick Installation

CISCO SYSTEMS

Model No. **PCM1000**

1 Install the Driver

IMPORTANT: Make sure to run the Setup Utility before installing the Adapter or the Setup won't work,

A Insert the Setup Utility CD into your PC's CD-ROM drive.

B The Setup Utility's Welcome screen should appear on your monitor. If it does not, this means the Setup Utility is not automatically running as it should. Start the Setup Utility manually by clicking the **Start** button, selecting **Run**, and typing **d:\setup.exe** (where "D" is your PC's CD-ROM drive).

Click the **Install** button.

C The *Welcome* screen will appear. Click **Next**.

D The *Choose Destination Location* folder will appear next. To install the driver in the default folder location, click **Next**.

B


InstallShield Wizard
Welcome to the InstallShield Wizard for Gigabit Notebook Adapter
The InstallShield® Wizard will install Gigabit Notebook Adapter on your computer. To continue, click Next.
< Back
Next >
Cancel

C


InstallShield Wizard
Choose Destination Location
Select folder where Setup will install files.
Setup will install Gigabit Notebook Adapter in the following folder.
To install to this folder, click Next. To install to a different folder, click Browse and select another folder.
Destination Folder
C:\Program Files\Gigabit Notebook Adapter
Browse...
InstallShield
< Back
Next >
Cancel

D_1

To install the driver in a different folder, click **Browse** and select a folder location. Then, click **Next**.

E The driver files will be copied onto your PC.

F This screen will appear when the installation is complete. Click **Finish**.

G Click the **Exit** tab to exit the Utility.

Continue to Step 2 to install the Adapter.



D_2



E



F

2 Install the Hardware

A Make sure that your Notebook PC is turned off.

B Locate your PC's PCMCIA slot (usually located on the side). Insert the pin end of the Gigabit Notebook Adapter into the slot with the LEDs facing up. Make sure that the Adapter seats firmly in place.

C Connect an Ethernet cable to the Ethernet port on the Adapter, then connect the other end to the Ethernet port on the switch or other networking device.

The setup and hardware insttallation are complete.

B

C

LINKSYS®
A Division of Cisco Systems, Inc.

For additional information or troubleshooting help, refer to the User Guide on the Setup CD-ROM. You can also call or email for further support.

24-hour Technical Support
800-326-7114
(toll-free from US or Canada)
E-mail Support
support@linksys.com
Website
http://www.linksys.com or
http://support.linksys.com
RMA (Return Merchandise Authorization)
http://www.linksys.com/support
FTP Site
ftp://ftp.linksys.com
Sales Information
800-546-5797 (800-LINKSYS)

Linksys is a registered trademark or trademark of Cisco Systems, Inc. and/or its affiliates in the U.S. and certain other countries. Copyright © 2005 Cisco Systems, Inc. All rights reserved.

PCM1000-QI-50329NC BW